



- NOTES:
1. PANEL EXTERNAL, VOLT NOT USED.
 2. CAPACITORS OF THIS TYPE ARE SHOWN IN THIS PLAN.
 3. GAIN AND LOSS ARE SHOWN AT 5 WAT.
 4. SWR OR SWR LOSS ARE NOT CALIBRATED.
 5. USED IN KWM-2 ONLY.
 6. POINT CONNECTION TO USE ON CHASSIS AND NOT ON OR WHEN NOISE BLANKER IS INSTALLED.
 7. USED IN KWM-2A ONLY.
- EXTERNAL CIRCUITRY
- A1 SWITCHES
- TO VCC
 - GROUND
 - +275 VDC
 - W- VOLT POWER PLUS (50W-1) OR (50W-1)
- EXTERNAL CIRCUITRY
- A2 SWITCHES
- TO VCC
 - GROUND
 - +275 VDC
 - W- VOLT POWER PLUS (50W-1)
- EXTERNAL CIRCUITRY
- A3 SWITCHES
- TO VCC
 - GROUND
 - +275 VDC
 - W- VOLT POWER PLUS (50W-1)
- 24 VOLT POWER PLUS (50W-1)

KWM-2/2A 6th ed Feb 1968

Figure 7-1. KWM-2 and KWM-2A Transceivers, Schematic Diagram

